


## Ignition coils, checking

### Notes:

- ◆ Check wiring between power output stage and ignition coils, and between the ignition coils and the connector set in the connector bracket, for insulation damage.
- ◆ Component locations ⇒ [page 28-1](#) .

### Checking secondary resistance

- Disconnect ignition wires from the ignition coils.



A

- Switch Fluke 83 multimeter to resistance range and connect between the two posts of the ignition coil being tested.

Specified value: 9000-14000  $\Omega$

If the specified resistance is not obtained for any one coil:


- Replace ignition coil.

### Checking primary resistance

- Disconnect power output stage harness connector ⇒ [page 28-7](#) .
- Check connectors for loose, corroded terminals or terminals that have been pushed out of their connector housing, and repair as necessary.

#### **Note:**

*The connector sequence in the connector bracket is immaterial because all three B+ terminals route to the ignition coils.*

**A**

- Connect one multimeter test leads between ignition coil connector terminal in connector bracket...

**A**

... and 3-pin power output stage connector (for each coil).


Specified value: max. 5.0  $\Omega$

If the specified resistance is not obtained for any coil:

- Replace ignition coil.

### Checking voltage supply

- Fuse for ignition coils OK
- Disconnect white connector on connector bracket ⇒ [page 28-1](#) .
- Switch ignition on.



A

- Switch Fluke 83 multimeter to voltage range and connect in sequence between Ground (GND) and all three terminals of the connector.

Specified value: approx. battery voltage

If the specified values are not obtained:

- Check for open circuit using wiring diagram, repair as necessary, also check fuses.