


## Ignition system, servicing

- 1 - Engine Control Module (ECM) -J192-**
- 2 - ECM signal wires**
  - ◆ 4-pin, light-brown
- 3 - Power output stage -N122-**
  - ◆ For ignition coils
- 4 - Ignition coil primary connections**
  - ◆ 3-pin, dark brown
- 5 - Harness connector**
  - ◆ 3-pin
  - ◆ For Knock Sensor (KS) 2 -G66-
- 6 - Camshaft Position (CMP) sensor -G40-**
- 7 - Engine speed (RPM) sensor -G28-**
- 8 - Crankshaft Position (CKP) sensor -G4-**
- 9 - Knock Sensor (KS) 2 -G66-**
- 10 - Ignition coils 1, 2 and 3; -N-, -N128- and -N158-**



**11 - Knock Sensor (KS) 1 -G61-**

**12 - Spark plug connector**

**13 - Harness connector**

◆ 3-pin, gray

◆ For engine speed (RPM) sensor -G28-

**14 - Harness connector**

◆ 3-pin, black

◆ For Crankshaft Position (CKP) sensor -G4-

**15 - Harness connector**


◆ 3-pin

◆ For Knock Sensor (KS) 1 -G61-

**16 - Harness connector**

◆ 3-pin, white, voltage supply

◆ For ignition coils 1, 2 and 3, -N-, -N128- and -N158-



**17 - To fuse for ignition coils**

**18 - ECM connector E**

◆ 12-pin, black

**19 - ECM connector A**

◆ 24-pin, black

**20 - ECM connector B**

◆ 24-pin, red

**21 - ECM connector C**

◆ 24-pin, brown

**22 - ECM connector D**

◆ 12-pin, brown

**Technical data**

<b>Engine code</b>	<b>AFC</b>	
Idle RPM <sup>1)</sup> <ul style="list-style-type: none"> <li>• NOT adjustable; regulated by Idle Speed Control (ISC)</li> </ul>	650 to 750 RPM	
Engine speed limiting (upper limit) <ul style="list-style-type: none"> <li>• By switching off fuel injectors</li> </ul>	6200 RPM	
Firing order	1 - 4 - 3 - 6 - 2 - 5	
Spark plugs	Tightening torque	30 Nm (22 ft lb)
	Part No.	101 000 033 AA
	Manufacturer code	BKUR 6 ET - 10
	Electrode gap	0.9 to 1.1 mm (0.035 to 0.041 in.)
	Replacement interval	Every 37,000 miles or every 3 years (whichever occurs first)

<sup>1)</sup> Idle speed ⇒ [page 24-16](#) .

## Safety measures

### **WARNING!**

***Be alert when working on or near the engine. High ignition secondary voltage can cause serious personal injury and damage vehicle components.***

- ◆ DO NOT touch or disconnect ignition system wires when the engine is running or being cranked at starting RPM.***
- ◆ DO NOT operate the starter if the fuel injectors have been removed.***

***Be sure the ignition is switched OFF, when:***

- ◆ Disconnecting ignition wires***
- ◆ Disconnecting fuel injection system wiring***
- ◆ Connecting or disconnecting test equipment leads***
- ◆ Disconnecting the battery***
- ◆ Washing the engine or engine compartment.***

***BEFORE cranking the engine at starting RPM (such as for compression testing) disable the ignition and fuel injection systems:***

- ◆ ***Disconnect the ignition coil power output stage.***
- ◆ ***Disconnect harness connectors from all six fuel injectors.***
- ◆ ***After the work is completed, erase Diagnostic Trouble Code (DTC) memory.***

**CAUTION!*****BEFORE disconnecting the battery:***

- ◆ ***Stop the engine.***
- ◆ ***Be sure the ignition is switched OFF (also applies when connecting the battery). Failure to do so may damage the Engine Control Module (ECM).***
- ◆ ***Be sure of the proper radio code (for vehicles equipped with coded anti-theft radio).***

***Be sure the battery negative (-) cable is disconnected, when:***

- ◆ ***Working on the electrical system***
- ◆ ***Resistance (spot) welding or electric arc welding anywhere on the vehicle.***

***When connecting and disconnecting electrical test equipment (LED voltage tester, multimeter, etc.):***

- ◆ ***Be sure the ignition is switched OFF.***
- ◆ ***Use correct adapters from the VW 1594***

***connector test kit.***

***For any work affecting the Engine Control Module (ECM):***

- ◆ BEFORE disconnecting the ECM harness connector, switch the ignition OFF and WAIT at least 20 seconds. Failure to do so may damage the ECM.***
  
- ◆ DO NOT connect any outside voltage source to stimulate an output signal at the ECM.***