

Wheels and tires


WARNING!

- ◆ *Do not re-use any fasteners that are worn or deformed in normal use.*
- ◆ *Some fasteners are designed to be used only once, and are unreliable and may fail if used a second time. This includes, but is not limited to, nuts, bolts, washers, circlips and cotter pins. Always follow the recommendations in this manual—replace these fasteners with new parts where indicated, and any other time it is deemed necessary by inspection.*

Notes:

- ◆ *The approved wheel/tire combinations had not been finalized at the time of printing of this Repair Manual.*
- ◆ *For safety reasons, the tires should be replaced in pairs for one axle at a time or for both axles together; not individually.*
- ◆ *Always install tires with the deepest tread on the front axle.*

- ◆ *It is recommended to use tires of the same make, design and tread pattern on all four wheels.*
- ◆ *Install a new valve stem when installing a new wheel or tire.*
- ◆ *If using tires with a directional tread pattern, the spare tire should be mounted on the wheel with the tread pattern facing the same way as the tires on the right-side of the vehicle.*



Light-alloy wheel

1 - Tire

2 - Valve

- ◆ Always replace
- ◆ Use only correct valves as specified in parts catalog microfiche

3 - Wheel

- ◆ Bolt hole circle diameter: 112 mm (4.409 in.)

4 - Anti-theft wheel bolt M14 x 1.5 x 27.5

- ◆ 120 Nm (89 ft lb)

5 - Adapter for anti-theft wheel bolt

6 - Protective cap


- ◆ Install onto anti-theft wheel bolt

7 - Center cap

8 - Protective caps

- ◆ Install onto wheel bolts


44-3

**9 - Wheel bolts M14 x 1.5 x 27.5**

- ◆ 120 Nm (89 ft lb)

10 - Retainer springs for balancing weights**11 - Balancing weights**

- ◆ Maximum allowable weight: 60g (2.1 oz.) per rim flange



A

Fig. 1 Anti-theft wheel bolt

1 - Anti-theft wheel bolt

2 - Protective cap

3 - Wheel bolt adapter

Wheels, balancing on vehicle

Always deactivate the traction control system (ASR) before balancing the wheels.

Notes:

- ◆ *Incorrectly balanced wheels cause steering wheel vibration and shuddering at the front of the vehicle.*
- ◆ *Where applicable, position the vehicle on the sensor platforms (front axle only for front wheel drive, both axles for all wheel drive) in order to carry out wheel balancing.*
- ◆ *Observe the wheel balancing equipment manufacturer's operating instructions.*