


24-111




Vacuum connections

Vehicles with manual transmission

- 1 - Brake booster**
- 2 - Check valve**
- 3 - Vacuum canister**
 - ◆ For intake manifold change-over valve
- 4 - Check valve**
- 5 - Throttle body**
- 6 - Ignition coils**
 - ◆ Ignition coil 1 -N-
 - ◆ Ignition coil 2 -N128-
 - ◆ Ignition coil 3 -N158-
- 7 - Vacuum reservoir**
 - ◆ For intake manifold change-over valve
- 8 - Air cleaner**
- 9 - Intake manifold**
- 10 - Sensor for EVAP canister**

24-112



11 - EVAP canister

12 - EVAP canister purge regulator valve

13 - Fuel pressure regulator

14 - T-connector

◆ Only for vehicles with A/C and/or EGR

15 - Check valve

16 - T-connector

◆ Only for vehicles with A/C

17 - To A/C


18 - Intake manifold change-over valve

19 - EGR vacuum regulator solenoid valve

20 - Sound dampener

21 - EGR valve

24-113



Vehicles with automatic transmission

- 1 - Brake booster**
- 2 - Check valve**
- 3 - Vacuum canister**
 - ◆ For intake manifold change-over valve
- 4 - Vacuum booster**
- 5 - Throttle body**
- 6 - Ignition coils**
 - ◆ Ignition coil 1 -N-
 - ◆ Ignition coil 2 -N128-
 - ◆ Ignition coil 3 -N158-
- 7 - Vacuum reservoir**
 - ◆ For intake manifold change-over valve
- 8 - Air cleaner**
- 9 - Intake manifold**
- 10 - Sensor for EVAP canister**

