

01-74

Read Measuring Value Block (function 08)

Test requirements:

- Coolant Temperature at least 80 ° C.
- Electrical consumers switched off (radiator fan must NOT run during test).
- A/C switched off.
- Steering in "straight-ahead" position

Test sequence

- Connect VAS5051 tester or VAG1551 scan tool and select the control module for engine electronics using "address word" 01 ⇒ [Page 01-9](#).

Engine must run at idle for this.



When indicated on display:

- Press buttons -0- and -8- to select "Read Measuring Value Block" and press -Q- button to confirm input.

Rapid data transfer

HELP


Select function XX

Read Measuring Value Block Q
Input display group number XXX



When indicated on display:

- Enter desired three digit display group number and confirm by pressing the -Q- button.

**Note:**

Which display group should be chosen depends on current function and component tests.

⚡ Indicated on display for display group 000:

⚡ Indicated on display (example) for display group 001:

Notes:

◆ *Display can be printed out on the paper roll when printer is switched on.*

◆ *To switch to a different display group, proceed as follows:*

Display group	VAG1551 Scan Tool (ST)	VAS5051 tester
higher	Press button -3-	Press s button.
Lower	Press button -1-	Press t button.